





DSP-AEC-1010-DA

Upgrade Instruction


1. Read the REDME file included in the FW upgrade package.
2. Copy the update software “DSP_Upgrade_Tool_en” and firmware files to a PC.
3. Connect the PC to the same network as the DSP.
4. Open the “DSP_Upgrade_Tool_en”



5. Browse for the FW BIN file and select. Then click on “Next”.
6. The upgrade tool will now scan the network for available DSP-AEC-1010-DA. If the upgrade tool not finds any DSP:s make sure once again that the PC and DSP is connected to the same network.



7. Select the DSP:s that you want to perform the upgrade on and click start.
8. A progress bar will appear to show the installation process.



9. After the upgrade is done successfully, exit the upgrade tool and reboot the DSP.

